DIGIFIZmini SVoltmeter 00004 0 [] 0 οΠο DIGIFIZmini Fuse (1 A) Pin Function Color Switched Power bk 1 2 Dash Light gy/bu 3 Sensor Input gn -<u>ˈ</u>Ŏ҉-4 Ground bn ╋ Light Battery Ignition Operating Switch Switch Relay (53)

Installation Notes:

- Installation should only be done by experienced personnel
- Disconnect the battery before doing any work to vehicle electronics
- For best accuracy connect ground as close to signal source as possible
- One relay and one fuse are enough for up to ten DIGIFIZminis
- Crimping should always be preferred to soldering
- For accurate readings connect sensor input directly to the battery